2022 Light Commercial Products







CLASS AGENDA

- Light commercial equipment review
- Understanding Carrier Nomenclature
- Installation
- Component setup/operation
 - Central Terminal Board
 - Defrost Board
 - Ignition Gas Control Board
- Troubleshooting



PRODUCT OFFERINGS

Good WEATHERMAKER Standard Efficiency

Better WEATHERMASTER High-Efficiency

WEATHEREXPERT Ultra-High Efficiency

Best

48/50 KC (3-6 ton) 48/50 TC (6-27.5 ton) 48/50 HC (3-25 ton)

48/50 LC (3-5 ton)

Common style CTB and standard drive blower assembly

48/50 FC (3-6 ton)

48/50 GC (3-5 ton)

48/50 JC (3-5 ton) Variable Speed

Updated CTB and New EcoBlue Blower assembly

48 means Gas Heat with AC
50 means Elec Heat with AC
Heat Pumps will be 50**Q example: 50TCQ, 50GCQ, 50FCQ



BRANT SLIDE NEEDS UPDATING PRODUCT OFFERINGS

Good Preffer Standard Efficiency	Better WEATHERMASTER High-Efficiency	WEATHEREXPE	Best RT Ultra-High Efficiency				
48/50 KC (3-6 ton) 48/50 TC (6-27.5 ton)	48/50 HC (3-25	ton)	48/50 LC (3-5 ton)				
Common style CTB and standard drive blower assembly							
48/50 FC (3-6 ton)	48/50 GC (3-5 to	on)	48/50 JC (3-5 ton) Variable Speed				
Updated CTB and New Axion Blower assembly							
48 means Elec(AC) with 0 50 means Elec(AC) with I Heat Pumps will be 50 ** <u>C</u>							



WHY TECHNICAL SUPPORT NEEDS THE FULL MODEL NUMBER

48FC MODEL NUMBE	R NOMENCIATURE
	11 12 13 14 15 16 17 18
Example: 4 8 F C D A 0 4 A 2	A 5 - 0 A 0 A 0
Unit Heat Type	Packaging & Seismic Compliance
48 – Gas Heat Packaged Rooftop	0 = Standard
	1 = LTL
Model Series - WeatherMaker®	
FC-14.0 SEER Standard Efficiency, sizes 04-06	Electrical Options
15.0 IEER Standard Efficiency, size 07	A = None C = Non-Fused Disconnect
	D = Thru-The-Base Connections
Heat Size D = Low Gas Heat	F = Non-Fused Disconnect and
E = Medium Gas Heat	Thru-The-Base Connections
F = High Gas Heat	
L = Low NOx – Low Gas Heat'	Service Options
S = Low Heat w/ Stainless Steel Exchanger R = Medium Heat w/ Stainless Steel Exchanger	0 = None 1 = Unpowered Convenience Outlet
R = Medium Heat w/ Stainless Steel Exchanger T = High Heat w/ Stainless Steel Exchanger	1 = Unpowered Convenience Outlet 2 = Powered Convenience Outlet
(Low NOx models include Stainless Steel HX)	3 = Hinged Panels
	4 = Hinged Panels and
Refrig. Systems Options	Unpowered Convenience Outlet 5 = Hinged Panels and
A = Standard One Stage Cooling Models1	Powered Convenience Outlet
B = Standard One Stage Cooling Models with Humidi-MiZer [®] system ^{1, 3}	
M = Single Circuit, Two Stage Cooling ^{2,3}	Intake / Exhaust Options
N = Single Circuit, Two Stage Cooling with	A = None
Humidi-MiZer system ²	B = Temperature Economizer w/ Barometric Relief
	F = Enthalpy Economizer w/ Barometric Relief K = Two-Position Damper ¹
Cooling Tons	U = Temperature Ultra Low Leak Economizer
04 = 3 tons 05 = 4 tons	w/ Barometric Relief
06 = 5 tons	W= Enthalpy Ultra Low Leak Economizer
07 = 6 tons	w/ Barometric Relief
	Base Unit Controls
Sensor Options A = None	0 = Electro-mechanical Controls - can be used with
B = Return Air (RA) Smoke Detector	field-installed W7212 EconoMi\$er® IV
C = Supply Air (SA) Smoke Detector	(Non-Fault Detection and Diagnostic) 2 = RTU Open Multi-Protocol Controller
D = RA + SA Smoke Detector	2 = RTO Open Multi-Protocol Controller 3 = SystemVu™ Controls
E = CO ₂ Sensor F = RA Smoke Detector and CO ₂ Sensor	6 = Electro-mechanical Controls - can be used with W7220
G = SA Smoke Detector and CO ₂ Sensor	EconoMi\$er X (with Fault Detection and Diagnostic)
H = RA + SA Smoke Detector and CO ₂ Sensor	
J = Condensate Overflow Switch	Design Revision
K = Condensate Overflow Switch and RA Smoke Detector L = Condensate Overflow Switch and RA and SA Smoke Detectors	 Factory Design Revision
M = Condensate Overflow Switch and SA Smoke Detectors	
	Voltage 1 = 575/3/60
Indoor Fan Options	3 = 208-230/1/60'
1 = Direct Drive - EcoBlue - Standard Static	5 = 208-230/3/60
2 = Direct Drive - EcoBlue - Medium Static	6 = 460/3/60
3 = Direct Drive – EcoBlue – High Static	
	1 Size 04/05/06 models only
Coil Options – (Outdoor - Indoor - Hail Guard) A = Al/Cu - Al/Cu	² Size 07 models only ³ Units with Humidi-MiZer System include Low Ambient controller
B = Precoat Al/Cu - Al/Cu	onno wan numur-much system include Low Ambient controller
C = E-coat Al/Cu - Al/Cu	Note: On single phase (-3 voltage code) models, the
D = E-coat Al/Cu - E-coat Al/Cu	following are not available as a factory-installed option:
E = Cu/Cu - Al/Cu	 Humidi-MiZer System
F = Cu/Cu - Cu/Cu M = Al/Cu -Al/Cu — Louvered Hail Guard	Two-Position Damper Coated Coils or Cu Fin Coils
N = Precoat Al/Cu - Al/Cu - Louvered Hail Guard	Louvered Hail Guards
P = E-coat Al/Cu - Al/Cu - Louvered Hail Guard	 Economizer or 2-Position Damper
Q = E-coat Al/Cu - E-coat Al/Cu Louvered Hail Guard	 Powered 115 Volt Convenience Outlet
R = Cu/Cu - Al/Cu - Louvered Hail Guard	

CE

MODEL NUMBER NOMENCLA	TURE
-----------------------	------


090 = 90,000

130 = 130.000

- Perfect Humidity - Coated Colls or Cu Fin Colls

- Louvered Hail Guards Economizer
 Powered 115 Volt Convenience Outlet

Note: On single phase (-J voltage code) models, the following are not available as a factory installed option:



Coil Options (RTPF) (Outdoor - Indoor - Hail Guard) A = Al/Cu - Al/Cu

- B = Precoat Al/Cu Al/Cu
- C = E-coat Al/Cu Al/Cu D = E-coat Al/Cu E-coat Al/Cu

- N = Precoat Al/Cu Al/Cu Louvered Hail Guard P = E-coat Al/Cu Al/Cu Louvered Hail Guard Q = E-coat Al/Cu E-coat Al/Cu Louvered Hail Guard
- R = Cu/Cu Al/Cu Louvered Hail Guard S = Cu/Cu Cu/Cu Louvered Hail Guard

WHAT'S IN THE MODEL NUMBER?

Position: 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18]
Example: 5 0 T C - A 0 A<	Image: Section State Stat



SERIAL NUMBER BREAKDOWN

1418PXXXXX

The first 4 numbers indicate the week and year the unit was built






General Installation

Curb Unit Power and Gas


CURB UNIT ELECTRICAL POWER AND GAS






CURB UNIT ELECTRICAL POWER AND GAS








GAS LINE ROUTING




CONDENSATE DRAINAGE



ĈE

CONDENSATE DRAIN PIPING DETAIL


Condensate Trap (Using PVC)





CONDENSATE DRAIN PIPING DETAIL

Condensate Bottom Drain








Heat Pump 38AUQ Air Conditioner Single Stage 38AUZ Air Conditioner 2-Stage Stage 38AUD









Refrigerant Piping Systems



Refrigerant Piping Concerns

- Application
- Length of Piping
- Routing & Obstacles
- Pressure Drop vs. Capacity Loss
- Oil Return at Minimum Capacity
- System Charge
- Liquid at the metering device
- Protect the compressor
 - Liquid slugging oil & refrigerant
 - Off-cycle protection



Improper line size can cause problems


- Compressor Failures
 - Floodback
 - Slugging
 - Oil Loss
 - Overheating
- Poor Evaporator Performance
 - Flash Gas At TXV
 - Low SST's
 - Frosting




- 1. Keep it simple, keep it short
- 2. Size piping based on the best compromise of pressure loss and cost
- 3. Design for oil return in vapor lines at minimum load conditions
- 4. Avoid oil and liquid refrigerant traps
- 5. Design for liquid at the expansion valve
- 6. Limit system charge to 4 lbs./ton
- 7. Support the piping adequately
- 8. Provide valves and access fittings for service
- 9. Insulate piping where needed

CE


TYPICAL ORIENTATIONS




OUTDOOR LOCATIONS



Do Not Bury Lines!







Max. Piping Length depends on the application

- Always keep both run and lift as short as possible.
- Air conditioning systems.
 - Maximum run 200 linear feet
 - Maximum lift depends unit model and refrigerant
- Heat pumps 100 linear feet maximum.
- Equivalent feet = Linear feet of pipe + Equivalent feet of fittings, valves and specialties.
- Consult Product Data and Installation Instructions for piping recommendations.
 - Use System Design Manual, ASHRAE design guide or Refrigerant Piping Design program for special applications or to verify if existing piping is adequate.



FITTING PRESSURE DROP

	Smooth Bend Elbows					Smooth Bend Tees				
Normal	90° 90°		90°	45°	45°	180°	Flow-	Straight-Thru Flow		
Pipe or Tube Size (in.)	Std*	Rad. †	Street*	Std*	Street*	Std*	Thru Branch	No Reduction	Reduced ¹ / ₄	Reduced ^{1/2}
3/8	1.2	0.8	2.1	0.6	0.9	2.1	2.4	0.8	1.0	1.2
1/2	1.4	0.9	2.3	0.7	1.1	2.3	2.7	0.9	1.2	1.4
5/8	1.6	1.0	2.5	0.8	1.3	2.5	3.0	1.0	1.4	1.6
3/4	1.8	1.2	2.9	0.8	1.4	2.8	3.5	1.2	1.7	1.8
7/8	2.0	1.4	3.2	0.9	1.6	3.2	4.0	1.4	1.9	2.0
1 1/8	2.6	1.7	4.1	1.3	2.1	4.1	5.0	1.7	2.2	2.6
1 3/8	3.3	2.3	5.6	1.7	3.0	5.6	7.0	2.3	3.1	3.3
1 5/8	4.0	2.6	6.3	2.1	3.4	6.3	8.0	2.6	3.7	4.0
2 1/8	5.0	3.3	8.2	2.6	4.5	8.2	10.0	3.3	4.7	5.0
2 5/8	6.0	4.1	10.0	3.2	5.2	10.0	12.0	4.1	5.6	6.0
3 1/8	7.5	5.0	12.0	4.0	6.4	12.0	15.0	5.0	7.0	7.5
3 5/8	9.0	5.9	15.0	4.7	7.3	15.0	18.0	5.9	8.0	9.0
4 1/8	10.0	6.7	17.0	5.2	8.5	17.0	21.0	6.7	9.0	10.0
5 1/8	13.0	8.2	21.0	6.5	11.0	21.0	25.0	8.2	12.0	13.0
6 1/8	16.0	10.0	25.0	7.9	13.0	25.0	30.0	10.0	14.0	16.0




- Suction Line Design
 - Keep It Short and Simple
 - Do not use oversized vapor lines or exceed maximum lengths.
 - In many situations a smaller size can be used without the increased pressure drop having significant impact on the system performance.
 - Pitch horizontal lines minimum 1/8 inch per foot in the direction of flow.
 - Use Suction Loop At Evaporators When Compressor Is Below To Prevent Drainage to Compressor



Double Suction Riser Detail


CE





OFF-CYCLE PROTECTION


Multiple Evaporators On Common Suction Line





WATCH OUT FOR SUCTION LINE TRAPS

When using the existing refrigerant piping from systems that used older reciprocating compressors the oil volume on many reciprocating compressors was around 2 gallons and the scrolls used today only hold around a ½ a gallon of oil and if there are existing trap's they can cause lack of oil return and premature compressor failures.





- Suction Line Design
 - TXV Bulb Location Is Critical
 - Do Not Install On Common Line Of Multiple Circuit Evaporators
 - Install on Vertical Line After Two Elbows To Ensure Good Mixing
 - DO NOT Bury Refrigerant Lines!
 - Accumulators Are Required In Long Line, VAV, VVT and Other High-Risk Applications
 - Vibration Eliminators are Not Recommended.



SUCTION LINE SUMMARY

- 1. Keep the path as short and simple as possible.
- Design lines for a 2°F line loss. Remember this is only a guideline for sizing. In many situations a smaller size can be used without the increased pressure drop having significant impact on the system performance.
- 3. Check for oil return at the minimum load condition.
 - a. Use a reduced riser size first, if does not work then use a double suction riser.
- 4. Pitch horizontal lines minimum 1/8 inch per foot in the direction of flow.
- 5. Loop the piping to prevent drain back to the compressor in the off cycle.
- 6. Do not put in intermediate traps in the risers or a trap at the base of a suction riser.
- 7. Insulate the entire suction line.
- 8. Provide valves to isolate the line for compressor service and provide gauge ports.
- 9. Install suction accumulator where necessary.



Liquid Line Design


- Horizontal liquid lines can run parallel to the suction line.
- Do not exceed liquid lift recommendations
 - Risk of flashing before reaching the TXV
 - Loss of capacity
 - Increased head pressure due to static head
- Smaller is better!
 - Use smallest line to reduce refrigerant charge.



Install Liquid Line Solenoid Valves —


It is recommended that a bi-directional solenoid valve be placed in the main liquid line (see Figs. 5 & 6) between the outdoor unit and the indoor coil. Locate the solenoid valve at the end of the liquid line, near the outdoor unit connections, with flow direction arrow pointed at the outdoor unit. Refer to Table 5. (A liquid line solenoid valve is required when the liquid line length exceeds 75 ft [23 m].) This valve prevents refrigerant migration (which causes oil dilution) to the compressor during the off cycle, at low outdoor ambient temperatures. Wire the solenoid according to the unit label diagram.






CE

MOUNTING TXV BULB ON SUCTION LINE



- Please fully read the installation manual
- Correct piping is very critical





• Factory charge is 9lbs Refrigerant must be added. Subtract 9lbs from Charge and add for lineset

R-410A	Equivalent Length							
	Ft	0-38	38-75	75-113	113-150			
Model Nominal Capacity	Length Linear Length Equiiv	0-25 0-38	25-50 38-75	50-75 75-113	75-100 113-115			
38AUQ*07	Liquid Line	3/8	3/8	³ / ₈ ¹ / ₂	3/8 1/2			
	Max Lift Cool Heat	25 25	50 50	48 75 46 60	39 100 31 60			
	Vapor Line	7/8	7/8	1- ¹ /8	1- ¹ /8			
	Charge (lbs)	17.8	18.8	20.3 22.6	21.4 24.5			
38AUQ*08	Liquid Line	1/2	1/2	1/2	1/2			
	Max Lift Cool Heat	25 25	50 50	75 60	100 60			
	Vapor Line	7/8 1-1/8	1- ¹ /8	1- ¹ /8	1-1/8			
	Charge (lbs)	20.9	23.0	24.9	26.8			
	i	4	-	-	4 5			

Table 2 – 38AUQ*07-12 Piping Recommendations (Single-Circuit Unit)




COMMERCIAL SPLITS

- 40RUA air handler is cooling only
- 40RUQ air handler for heat pump applications
- Unit voltages 208/230/460
- Motors come wired for 460
- 208/230 applications you must wire 9 lead motor for low voltage operation.



COMMERCIAL SPLITS

• 9 Lead Motor wiring









General System Layout & Components

COMPRESSOR SECTION






SYSTEM SERVICE PORTS



HIGH-PRESSURE SWITCH






LOW-PRESSURE SWITCH






CONDENSER FAN




CE

GAS HEAT CONTROL BOX




INTEGRATED GAS CONTROL BOARD






GAS HEAT SECTION



CE

BURNER ASSEMBLY




MEASURING MANIFOLD PRESSURE




CE

HEAT PUMP CONTROL BOX




CE

HEAT PUMP COMPONENTS



MORE HEAT PUMP COMPONENTS




LOSS OF CHARGE PRESSURE SWITCH






FREEZE PROTECTION THERMOSTAT SWITCH






REVERSING VALVE




DEFROST THERMOSTAT






HEAT PUMP COILS




CE

THERMOSTATIC EXPANSION VALVE


TXV for Ultra-High Efficiency Units:




INDOOR FAN



SAFETY SWITCH










MOTOR CONNECTIONS





New Vane Axial Blower Assembly




Single Phase HK50AA055



CE




Three Phase HK50AA058



ELECTRIC HEAT

Use holes in sidewall from blank-off panels to secure heaters into position






INDOOR AIR FILTERS



CE

NOVATION[®] MCHX CONDENSER COILS






WHAT IS NOVATION™ CONDENSER COIL




Novation[™] Heat Exchanger Technology

- Aluminum Flat Tube Multi Port Design
- Aluminum Wave Fin Pattern
- Structurally Robust / Easy To Clean
- E-Coating required for coastal and industrial applications












Central Terminal Board - CTB

CENTRAL TERMINAL BOARD

Total of 11 terminal strips:

J1-J2: Screw terminals for (thermostat wires) 0.046-in square pin

Total of 18 quick-connect terminals









LFAN SPEED SET UP CONTROLS UCB Fan Speed Controls - 3-Phase Units ECOBIUE CTB

Standard CTB Newer boards are blue


CTB: JUMPERS

- JMP1 Phase Monitor ٠
- JMP2 Occupancy Control ٠
- JMP3 Smoke Detector Shutdown ٠
- JMP4 **Remote Shutdown** •
- JMP5, 6, 7 Heat Pump / Reheat ٠





Wire Diagram Found on Equipment of CTB



JUMPERS 1 + 2

• Jumper 1

Phase Monitor Accessory

- Phase Monitor Relay power between 2 + 3
- Opens Red-Pink of Phase Monitor Relay
 - Removes 24 vac from Remote Shutdown + Smoke Shutdown
- Result

CE

• Immediate unit Shutdown

• Jumper 2

Occupancy Jumper

- Occupancy: Used to signal Building occupied and Min Economizer ventilation when IFM energized
- Removes power to Economizer Control "N"
- Result
 - Economizer closes until it gets a call for free cooling or ventilation.

JUMPERS 3 + 4

• Jumper 3

Smoke Detector

- Allows Smoke Detector to control signal (Open contacts) to force unit "OFF"
- Removes Transformer "R" from Terminal Board
- Result: Immediate unit shutdown

- Jumper 4 Remote Shutdown
 - Allows remote contacts (NC) to control unit "ON" or "OFF"
 - Removes Transformer "R" from Terminal Board
 - Result: Immediate unit shutdown



JUMPERS 5 + 6

• Jumper 5

Used with R/H or Heat Pump

- Opens "Y1" from Econo (pin 2), Reheat/Heat Pump (pin 6), CLO/Comp1 (pin 4)
- Allows RH control board to send signal CLO 1 controlling compressor 1 (pin 4)

• Jumper 6

Used with R/H or Heat Pump

- Opens "G" from Reheat/Heat
 Pump (pin 1), IFM signal return
 (pin 2) and "G" from Control Board
 (pin 1)
- Allows RH control board to control IFM



JUMPER 7


• Jumper 7

Used with R/H or Heat Pump

- Opens "Y2" from Econ (pin 3), Reheat/Heat Pump (pin 8)
- Allows Reheat/Heat Pump board to send signal to CLO 2 (pin 4) controlling Compressor 2




24 Volt Troubleshooting (Power)



Safeties that can break 24vac to R-Connection


- The IFMOL Indoor fan motor overload limit
- Limit switches
- Roll Out switches
- Smoke detectors if installed
- Phase monitor if installed


24 Volt Troubleshooting (Y1 Cooling)






PATH OF POWER Low Voltage – Stand by







PATH OF POWER Low Voltage – Fan






PATH OF POWER Low Voltage – 1st Stage Cooling






PATH OF POWER Low Voltage – 2nd Stage Cooling




_____'




PATH OF POWER

Low Voltage – 1st Stage Electric Heating 2nd Stage Electric Heating is the same

24VAC to W1
 To Electric Heat Contactor






PATH OF POWER Low Voltage – Heat Pump Cooling

- 1. 24VAC to Y1
- 2. To Economizer
- 3. Back to 1st Stage Cooling Jumper (cut)
- 4. To Defrost Board Y1 Input
- 5. Comp 1/RV1 Outputs made
- 6. Through Freeze Protection Stat
- 7. To Unit Safeties (HPS1/LPS1)
- 8. To 1st Stage Contactor (C1)

Y2, W1, and W2 work the same. Their signal is sent to the Defrost Board which controls the outputs for Reversing Valves, Compressors and Electric Heat. Notice also that the fan Jumper (JMP6) is cut. The Defrost Board also controls the fan operation.

CE operatio



PATH OF POWER Low Voltage – Gas Heating

1. 24VAC to W1 2. Signal sent to W on IGC 3. IGC goes through Sequence and eventually opens gas valve.


(CR


HV Tran

12


Ш нs

Note that G signal goes to IGC. IGC takes control of Indoor Fan.






CLASS EXERCISE NO COOLING CALL WHAT IS WRONG ?



CLASS EXERCISE NO HEATING ON A CALL FOR GAS HEAT ?






Heat Pump Operation


HEAT PUMP OPERATION

- Commercial heat pumps use a conventional Heat / Cool thermostat
 DO NOT use O
- W1 from the thermostat energizes both compressors in the Heat mode.
- W2 from the thermostat energizes the electric heat






DEFROST






DEFROST INTERVAL




DIP-SWITCHES



SWITCH 1	SWITCH 2	TIME	
ON	OFF	30 MINUTES	
OFF	ON	60 MINUTES	
OFF	OFF 90 MINUTES		
ON	ON	120 MINUTES	




DEFROST THERMOSTAT (DFT)






SPEED-UP PINS





CLO & Comfort Alert

CLO Wiring and Operation




CE

The CLO is energized by a 24 volt signal to terminal 2. Terminal 3 is 24 volts out to the contactor after passing the safeties. One load wire going to the compressor after the contactor goes through the sensor loop. If the #2 terminal has 24 volts and there is no amperage sensed going through the loop the #3 wire is deenergized locking out the compressor.

- 1 24 Volt Common
- 2 Y 24 volt control input
- 3 24 volt out to safeties / compressor contactor
- X 24 volt to trouble light if used

CLO CONNECTIONS





Controls

 Comfort Alert Diagnostic Module










 * "Alert" Light Blinks When Any Of 8 Harmful System Conditions Is Detected


<u>Alert Code</u>	System Condition	Diagnostic Alert Light	Lockout?
Code 2	System Pressure Trip	Blinks 2 Times	YES
Code 3	Short Cycling	Blinks 3 Times	YES
Code 4	Locked Rotor	Blinks 4 Times	YES
Code 5	Open Circuit	Blinks 5 Times	NO
Code 6	Missing Phase	Blinks 6 Times	YES
Code 7	Reverse Phase	Blinks 7 Times	YES
Code 8	Welded Contactor	Blinks 8 Times	NO
Code 9	Low Voltage	Blinks 9 Times	NO

Protective Faults That Result In Compressor Lockout



Comfort Alert Connections








Sensing Motor Protector Trips


- Comfort Alert Detects A Motor Trip
 When:
 - Thermostat Demand "Y" Is On
 - No Current Is Measured To Compressor
- Interpretation: Compressor Isn't Operating When System Demand Is Present
- Root Causes
 - LPS, HPS Open
 - Motor Protector Open
 - Power Disconnected (Fuse, Switch, Etc.)
 - Comfort Alert Not Wired Properly





Sensing System Pressure Trip Code 2


- Comfort Alert Detects System Pressure Code When:
 - Four Consecutive Protector Trips Occur
 - The Average Run Until Trip Time Is Between 1 Minute And 15 Minutes
- Interpretation: High Pressure Condition Causes Compressor To Run Briefly Before Tripping
- Root Causes
 - Blocked Condenser Coils
 - Condenser Fan Not Running
 - LPS





Sensing Short Cycling Code 3


- Comfort Alert Detects Short Cycling Code When:
 - A Pattern Of Short Cycles Emerges
 - Average Run Time For Past 4 Runs Is Less Than 3 Minutes
 - Normal End-of-Cycle (Y Input Removed)
- Interpretation: Compressor Is Running Only Short Periods Of Time
- Root Causes
 - Low Space Load
 - Faulty Thermostat





Sensing Locked Rotor Code 4


- Comfort Alert Detects Locked Rotor Code When:
 - Four Consecutive Protector Trips Occur
 - Y Demand Is Constant, Uninterrupted
 - The Average Run Until Trip Time Is Less Than 15 Seconds
- Interpretation: Compressor Is Attempting To Start But Cannot
- Root Causes
 - Low Line Voltage
 - Mechanical Issue With Compressor





Sensing Open Circuit Code 5

- Comfort Alert Detects A Open Circuit Code When:
 - Y Present, No Compressor Current For More Than 4 Hours (Protector Trip)
- Interpretation: Power Is Not Connected To Compressor
- Root Causes
 - Power Disconnected (Fuse, Switch, Etc.)
 - Failed Compressor Protector
 - Comfort Alert Not Wired Properly
 - Motor Leads Not Routed Through Comfort Alert Current Sensors





Sensing Missing Phase Code 6

Comfort Alert Detects A Code 6 When There is Power to Y or Y1 and:

- Time Frequency between T1 and T3 is within certain parameters depending on 50 or 60 Hz power supply when T2 is missing
- Either T1 or T3 Does Not Detect Current
- Both Events Have To Last One Second
- Interpretation: One Winding Of Compressor Not Getting Power
- Root Causes
 - Blown Fuse
 - Loose Or Broken Wires
 - Compressor Winding Damage






Sensing Reverse Phase Code 7

• Comfort Alert Detects A Code 7 When There is Power to Y or Y1 and:


- Time Frequency between T1 and T3 is within certain parameters depending on 50 or 60 Hz power supply for 1 Second. This Time Parameter is Different from Code 6.
- Interpretation: Two of the Phases are Reversed
- Root Causes
 - Supply Power Leads Not Routed Correctly
 - •From Power Source To Compressor





Sensing Welded Contactor Code 8

- Comfort Alert Detects A Welded Contactor Code When:
 - Current Is Detected Without "Y" Input
- Interpretation: Compressor Contactor Will Not Disengage
- Root Causes
 - Welded Contactor
 - Comfort Alert Not Wired Properly Demand Wire Bypassing Comfort Alert Module






Sensing Low Voltage Code 9

- Comfort Alert Detects Low Voltage Code When:
 - Comfort Alert 24VAC Is Below 18VAC
- Interpretation: Low Voltage Condition Exists
- Root Causes
 - Control Transformer Overloaded
 - Line Voltage Low

Auto-reset at 19 VAC 3-Minute Recheck





Multiple Alerts Condition

- If Multiple Alerts Occur, Comfort Alert Displays The First Code That Is Detected
 - -Allows Technician To Determine The Root Cause
- Example

- Low Line Voltage Leads To Locked Rotor Condition On Compressor

- Comfort Alert Displays Low Voltage Code Even While Locked Rotor Events Are Happening

- Protective codes (2,3,4,6,7,9) have Precedence over Non Protective Codes
- Over Current Sensed at Comfort Alert P-Terminal (1.5 +/-0.5 Amps) takes Precedence over Protective Code



CADM Resets

Automatic Reset

–Voltage Alert (Code 9) Resets When Voltage Rises Above 19VAC

Manual Reset

- All Alert Codes Can Be Reset By Cycling 24VAC Power

- Previous Code Will Flash 60 Seconds



CADM Memory

Comfort Alert Displays Last Alarm At Each Power Up


 Displays Code If Alarm Occurred During Last Power Cycle
 Display Lasts For One Minute

Alarm History Is Kept In Memory Comfort Alert Analysis Software Required Seven Day History Of Alarms Overall Count Of Alarms In Permanent History

Anti Short Cycle Timer

- -3 Minute Off Cycle after normal Shutdown
- -Time Delay not Active First 50 Starts
- RED LED Flashes during OFF Period










Integrated Gas Control - IGC

GAS HEAT CONTROLS AND HARDWARE




CE

IGC Board:

- Burner ignition and flame sensing
- Timed on/off control of the indoor fan
- Continuous monitoring of safety devices
- LED display of system status and error codes

IGC INTEGRATED GAS CONTROL







IGC FAULT CODES

LED FLASH CODE	DESCRIPTION	ACTION TAKEN BY CONTROL	RESET METHOD	PROBABLE CAUSE
On	Normal Operation	_	—	_
Off	Hardware Failure	No gas heating.	_	Loss of power to the IGC. Check 5 amp fuse on IGC, power to unit, 24V circuit breaker, transformer, and wiring to the IGC.
2 Flashes	Limit Switch Fault	Gas valve and igniter Off. Indoor fan and inducer On.	Limit switch closed, or heat call (W) Off.	High temperature limit switch is open. Check the operation of the indoor (evaporator) fan motor. Ensure that the supply-air temperature rise is within the range on the unit nameplate. Check wiring and limit switch operation.
3 Flashes	Flame Sense Fault	Indoor fan and inducer On.	Flame sense normal. Power reset for LED re- set.	The IGC sensed a flame when the gas valve should be closed. Check wiring, flame sensor, and gas valve operation.
4 Flashes	Four Consecutive Limit Switch Fault	No gas heating.	Heat call (W) Off. Power reset for LED re- set.	4 consecutive limit switch faults within a single call for heat. See Limit Switch Fault.
5 Flashes	Ignition Fault	No gas heating.	Heat call (W) Off. Power reset for LED re- set.	Unit unsuccessfully attempted ignition for 15 minutes. Check igniter and flame sensor elec- trode spacing, gaps, etc. Check flame sense and igniter wiring. Check gas valve operation and gas supply. Check gas valve connections to IGC terminals. BRN lead must be on Pin 11.
6 Flashes	Induced Draft Motor Fault	If heat off: no gas heat- ing. If heat on: gas valve Off and inducer On.	Inducer sense normal, or heat call (W) Off.	Inducer sense On when heat call Off, or induc- er sense Off when heat call On. Check wiring, voltage, and operation of IGC motor. Check speed sensor wiring to IGC.
7 Flashes	Rollout Switch Lockout	Gas valve and igniter Off. Indoor fan and inducer On.	Power reset.	Rollout switch has opened. Check gas valve operation. Check induced-draft blower wheel is properly secured to motor shaft.
8 Flashes	Internal Control Lockout	No gas heating.	Power reset.	IGC has sensed internal hardware or software error. If fault is not cleared by resetting 24 v power, replace the IGC.
9 Flashes	Temporary Software Lock- out	No gas heating.	1 hour auto reset, or power reset.	Electrical interference is disrupting the IGC software.




RESETTING FAULT CODES

CODE	ACTION	LOCKOUT	RESET MODE
1	Blower On/Off Delay Modified	No	Code Retained Until Unit's 24 Volts is Cycled
2	Limit Trip	Temporary	Cleared After Limit Switch Resets
3	Flame Sensing Error – Senses Flame When it Shouldn't	Temporary	Cleared After Error Clears
4	Four Consecutive Limit Trips in One Call for Heat	Yes – Soft	Cleared by Cycling "W" Signal
5	Ignition Lockout – Attempted Ignitions for 15 Minutes Without Success	Yes – Soft	Cleared by Cycling "W" Signal
6	Inducer Fault – Signal Between Board and Motor Do Not Match	Yes – Soft	Cleared by Cycling "W" Signal
7	Rollout Switch Opens	Yes – Hard	Lockout is Retained Until Unit's 24 Volts is Cycled
8	Control Fault – Detects Hardware or Software Failure	Yes – Hard	Lockout is Retained Until Unit's 24 Volts is Cycled
9	Safety Critical Code Fault – Detects Hardware or Software Failure	Temporary	Cleared After 1 Hour





BLOWN FUSE



CE

NORMAL OPERATION






LED ON



HARDWARE FAILURE




ĈE




LED OFF probable causes:

- 1. Loss of power to IGC.
- 2. Check fuse, power to the unit, 24 volt circuit breaker, transformer, and wiring.

EVAPORATOR FAN ON/OFF DELAY MODIFED






1 Flashes


IGC Fault Code 1 (1 flashes): Indicates a code that is not an error. The unit will continue to operate when this code is displayed.

The action taken by the control is 5 seconds subtracted from the On delay or 5 seconds added to Off delay (3 min max).

PROBABLE CAUSE: The high temperature limit switch opened during heat exchanger warm-up period before fan-on delay expired. The high temperature limit switch opened within 10 minutes of heat call (W) Off.

LIMIT SWITCH FAULT






2 Flashes

IGC Fault Code 2 (2 flashes): The action taken by the control will turn the gas valve and igniter off. The indoor fan and inducer will be turned on.


PROBABLE CAUSE: High temperature limit is open. Check the operation of the indoor fan motor. Ensure that the supply-air temperature rise is within the range on the unit nameplate. Check the wiring and limit switch operation.


LIMIT SWITCH





FLAME SENSE FAULT







3 Flashes

IGC Fault Code 3 (3 flashes): The action taken by the control is turn the indoor fan and inducer on.

PROBABLE CAUSE: The IGC sensed a flame when the gas valve should be closed. Check wiring flame sensor, and gas valve operation.

FOUR CONSECUTIVE LIMIT SWITCH FAULT







4 Flashes

IGC Fault Code 4 (4 flashes): The action taken by the control is no gas heat operation will occur.

PROBABLE CAUSE: 4 consecutive limit switch faults within a single call for heat. See Limit Switch Fault.

IGNITION FAULT





```
5 Flashes
```


IGC Fault Code 5 (5 flashes): The action taken by the control is no gas heating operation will occur.

PROBABLE CAUSE: The unit unsuccessfully attempted ignition for 15 minutes. Check igniter and flame sensor electrode spacing, gaps, etc. Check flame sense and igniter wiring. Check gas valve operation and gas supply.

IGNITION

IGC Fault Code 5 (5 flashes) will be displayed if the flame signal is lost during a call for heat. The control will attempt to re-ignite the furnace. If after 15 minutes of unsuccessful attempts to re-light the furnace, the control will lock-out and fault code 5 will be displayed.


Check for oxide build-up on the flame sensor and clean with fine steel wool. The flame sensor senses micro-amps and a build-up of oxide will interrupt the circuit. The flame sensor cannot be grounded or it will not operate. Also check the inlet gas pressure, control ground continuity, and the gas valve.





INDUCED DRAFT MOTOR FAULT






```
6 Flashes
```

IGC Fault Code 6 (6 flashes): The action taken by the control if the heat is off will be no gas heat operation, if the heat is on it will turn the gas valve and inducer off.

PROBABLE CAUSE: The inducer was sensed on when heat call was off, or the inducer was sensed off when heat call on. Check wiring, voltage, and operation of IGC motor. Check speed sensor wiring to IGC.

TROUBLESHOOTING HALL EFFECTS SWITCH



ĈE

Unplugged – reading circuit board

Pin #3 black lead and pin #1 red lead

Read 7.5-10 vdc

Pin #3 black lead and pin #2 red lead

Read 21-24 vdc

If outside these readings - Replace IGC

Plugged into circuit board

Same pin test point (1-3), rotate motor

Half turn reads <1 vdc, other half turn reads 6.5-9 vdc


Same pin test point (2-3), rotate motor


Will read 16-21 vdc

Anything outside of readings – Replace Hall Effect Sensor



Three Wire Plug





DC Meter Required



The Hall Effect Sensor is a magnetic device it send a signal to the board to verify the motor is running at the correct speed

Testing the IGC board

De-energize the IGC board Unplug the Hall Effect Sensor Energize the IGC board Set the thermostat in off position Set meter to DC volts 30vdc range Connect Black lead from meter to pin #3 of the board Connect the Red lead from the meter to pin #1 of the board you should read 7.5-10vdc Then move the Red lead from the meter to pin #2 of the board you should read 21vdc

If either of these 2 are out of range replace the IGC



Testing the Hall Effect Sensor

Re-plug the Hall Effect Sensor on to the IGC board Still with power applied to the IGC board Keep the thermostat in off position Connect Black lead from meter to pin #3 of the plug Connect the Red lead from the meter to pin #1 of the plug Now rotate the inducer motor by hand You should read 6.5-9vdc on half of the motor rotation and then >1vdc on the other half of the rotation. And keep alternating for each inducer motor rotation

Then move the Red lead from the meter to pin #2 of the board, you should now read 16.5-21vdc

If either of these 2 are out of range replace the Hall Effect Sensor




PRESSURE SWITCH HK06WC061

- Mounting Limitation: Switch diaphragm must be mounted vertically.
- Function: Normally Open to close on negative pressure rise of .18 +- .07 inches W. C. Minimum open/close pressure differential at .015 inches W.C.
- Maximum System Pressure 3.0 inches W. C.




CE



ROLLOUT SWITCH LOCKOUT






```
7 Flashes
```

IGC Fault Code 7 (7 flashes): The action taken by the control will be to turn the gas valve and igniter off, and the indoor fan and inducer on.

PROBABLE CAUSE: Rollout switch has opened. Check gas valve operation. Check induceddraft blower wheel is properly secured to motor shaft. This could also be an indication of a restricted heat exchanger.


ROLLOUT SWITCH





INTERNAL CONTROL FAULT






8 Flashes

IGC Fault Code 8 (8 flashes): A mandatory feature of the IGC board is the internal control fault. If something in the software changes, possibly due to electrical frequency interference, the internal built in software check will detect the software change, recognize that this may be a safety issue and shut down the entire gas system and the LED will flash eight (8) times. If this fault is observed, the board must be changed in order to operate the heating system.

SOFTWARE LOCKOUT






9 Flashes

IGC Fault Code 9 (9 flashes): In the event that electrical frequencies are interfering with or disrupting the operation of the software in the IGC board, the IGC board will temporarily lock out and stop unit operation for one (1) hour. Nine flashes of the fault code will be displayed. Reset will occur automatically in one (1) hour, or it can be reset manually by removing and replacing the 24-volt power from the board. If this problem persists, see your local equipment distributor for the addition of filters and signal chokes. All fault codes will be eliminated or lost if power to the unit or the IGC board is interrupted.

IGC ERROR CODES: FAULT 9




ĈE



Smoke Detector


SMOKE DETECTOR COMPONENTS SHIPPED TOGETHER



As received in the field, the components are mounted together.




ALIGN RETURN AIR DETECTOR



Rotate 90° (¹/₄-turn) to align parallel to filters.




ROTATE RETURN AIR DETECTOR



Rotate the return air detector end-to-end to where the elbow fitting is pointed down. Notice the mounting bracket has a slight bend to it.



ATTACH RETURN AIR DETECTOR TO CONTROLLER



Attach return air detector to controller using mounting bracket.




SMOKE DETECTOR

COMPLETING INSTALLATION OF THE SMOKE DETECTOR:

- Sampling tube is located across base pan return air opening without economizer
- Sampling tube is located in the economizer damper housing
- Sampling tube holes are on the bottom
- Connect the sampling tube to the return air detector with tubing
- Supply air sensor module is located in the indoor fan section
- Application tip See Catalog No. HKRNKA-1XA

CE



SMOKE DETECTOR WIRING

FIOP Smoke Detector Wiring and Response

All units: The FIOP smoke detector is configured to automatically shut down all unit operations when a smoke condition is detected. See Fig. 40, Smoke Detector Wiring.

Highlight A: The JMP 3 is factory-cut, transferring unit control to the smoke detector.

Highlight B: The smoke detector NC contact set will open on a smoke alarm condition, de-energizing the ORN conductor.


Highlight C: 24V power signal using the ORN lead is removed at the Smoke Detector input on the Central Terminal board (CTB); all unit operations cease immediately.

PremierLinkt and RTU--Open Controls: Unit operating functions (fan, cooling and heating) are terminated as described above. In addition:


Highlight D: On smoke alarm condition, the smoke detector NO Alarm contact will close, supplying 24V power to the GRA conductor.

Highlight E: The GRA lead at the Smoke Alarm input on LCTB provides a 24V signal to the FIOP DDC control.

CE



SMOKE DETECTOR WIRING




SMOKE DETECTOR WIRING




SMOKE DETECTOR WIRING

SMOKE DETECTOR WIRING






TYPICAL SMOKE DETECTOR CONNECTIONS





TYPICAL SMOKE DETECTOR CONNECTIONS





SMOKE DETECTOR: LED

Controller's Trouble LED is On

- Check the Trouble LED on each sensor connected to the controller. If a sensor's Trouble LED is on, determine the cause and make the necessary repairs.
- Check the wiring between the sensor and the controller. If wiring is loose or missing, repair or replace as required.

Controller's Trouble LED is Flashing

- 1. One or both of the sensors is 100% dirty.
- Determine which Dirty LED is flashing then clean that sensor assembly as described in the detector cleaning section.

Sensor's Trouble LED is On

- Check the sensor's Dirty LED. If it is flashing, the sensor is dirty and must be cleaned.
- Check the sensor's cover. If it is loose or missing, secure the cover to the sensor housing.
- 3. Replace sensor assembly.

Sensor's Power LED is Off

- Check the controller's Power LED. If it is off, determine why the controller does not have power and make the necessary repairs.
- Check the wiring between the sensor and the controller. If wiring is loose or missing, repair or replace as required.

Controller's Power LED is Off

- 1. Make sure the circuit supplying power to the controller is operational. If not, make sure JP2 and JP3 are set correctly on the controller before applying power.
- Verify that power is applied to the controller's supply input terminals. If power is not present, replace or repair wiring as required.

<u>Remote Test/Reset Station's Trouble LED Does Not</u> <u>flash When Performing a Dirty Test, But the</u> Controller's Trouble LED Does

- Verify that the remote test/station is wired as shown in Fig. 22. Repair or replace loose or missing wiring.
- Configure the sensor dirty test to activate the controller's supervision relay. See "Changing sensor dirty test operation."

Sensor's Trouble LED is On, But the Controller's Trouble LED is OFF

Remove JP1 on the controller.






Economizer

JADE ECONOMIZER




Ĉ

ECONOMIZER CIRCUIT – 1ST STAGE "Y1"





ECONOMIZER CIRCUIT – 2ND STAGE "Y2"








Humidi-mizer System

3 Modes




Combines the MoistureMi\$er system and ReHeat (RH) systems.

Adds a condenser bypass and additional coil to a standard RTU Circuit

CE

3 Modes




- Signal for Fan and First Stage Cooling come into Reheat Board
- Signal is sent out to run fan and compressor
- Valves are left at normal state position
- Outdoor condenser coil is used, HumidiMizer coil bypassed.




3 Modes

CE



- Signal for Fan, Cooling and Dehumidification come into Reheat Board.
- Signal is sent out to run fan and compressor.
- LSV Valve is energized.
- Outdoor condenser coil is used, HumidiMizer coil is used for sub cooling refrigerant.

3 Modes



- Signal for Fan and Dehumidification come into Reheat Board.
- Signal is sent out to run fan and compressor.
- Both valves are energized.

Hot Gas Reheat (HGRH) • Outdoor condenser coil is bypassed, HumidiMizer coil used for condensing refrigerant and reheating cold dry air from evaporator coil.



WHAT'S THE BENEFIT?

Each refrigerant circuit in a HumidiMiZer system can provide a total of 3 different modes of operation: *Normal, Sub-cooling, and Reheat modes*

- Control of each mode determined by call for DEHUM, Y1, or Y2
- Only physical change to the system is the refrigerant valves (Liquid Solenoid Valve & Discharge Solenoid Valve)
- Compressor stays running (except when in complete free cooling mode w/ economizer)


This results in a unit that can provide many ratios of Sensible/Latent capacity to match the demands of the space

- Up to 5 additional modes of unit operation for the unit on 2 stage systems.
- Must use Sequence of Operation table to determine how components are operating



Humidi-Mizer / Perfect Humidity


Sequence of Operation



- 1) Normal Mode Hot Conditions (approx. 20 DeltaT)
 - T > Set point, H < Set point
 - 55°F Supply Air
- 2) Sub cooling Mode Hot & Humid (approx. 10 DeltaT)
 - T > Set point, H > Set point
 - 60 65°F Supply Air
- 3) Hot Gas Reheat Mode Humid (approx. 0 DeltaT)
 - T < Set point, H > Set point
 - 75°F Neutral Air

DEHUMIDIFICATION CONTROLS

Central Terminal Board




Reheat Control Board




CE

INDOOR COILS




TROUBLESHOOTING THE HUMIDIMIZER CONTROL CIRCUIT



CE


CIRCUIT BOARD 24 VAC COMMON



24v common is any of the brown wires in control panel on any control board or component




CIRCUIT BOARD 24 VAC



CE


CONTROL BOARD - ECONOMIZER/REHEAT PIN - 1ST STAGE "Y1"



When HumidiMiZer Reheat board is added to a system. Jumper 1, 2 & 3 will be cut and removed.



CONTROL BOARD - ECONOMIZER/REHEAT PIN - 2ND STAGE "Y2"



When HumidiMiZer Reheat board is added to a system. Jumper 1, 2 & 3 will be cut and removed.




HUMIDIMIZER SOLENOID OUTPUTS - NORMAL MODE

DEMAND AND MODE			OUTPUTS			
Dehumidification Demand	Cooling Demand	Mode	Compressor	RDV	CLV	RLV (48/50FC 07 and 48/50GC 04-06 only)
No Power	No Power	No power	Off	De-energized (no flow)	De-energized (flow)	De-energized (flow)
No	No	Off	Off	De-energized (no flow)	De-energized (flow)	Energized (no flow)
No	Yes	COOL	On	De-energized (no flow)	De-energized (flow)	Energized (no flow)
Yes	Yes	DEHUM/MECH COOL	On	De-energized (no flow)	Energized (no flow)	De-energized (flow)
Yse	No	DEHUM	On	Energized (flow)	Energized (no flow)	De-energized (flow)



REHEAT CONTROL BOARD WIRING SCHEMATIC



LEGEND

COMP -- COMPRESSOR


- CR -- COOLING RELAY (24-VDC COIL, COM TO GROUND)
- DHR -- DEHUMIDIFICATION RELAY (24-VDC COIL)
- DSV --DISCHARGE LINE SOLENOID VALVE
- ECON -- ECONOMIZER
- GRD -- GROUND
- HR -- HEATING RELAY (24-VDC COIL)
- HSTAT -- HUMIDISTAT
- IFM -- INDOOR/SUPPLY FAN MOTOR
- LSV -- LIQUID (3-WAY) SOLENOID VALVE
- LTLO -- LOW TEMPERATURE LOCKOUT



Fig. 80 - Reheat Control Board Schematic

C132

REHEAT CONTROL BOARD – NORMAL MODE




CE

J2 pin connector is powered by Transformer 2. This transformer is designated for the reheat solenoid circuits only!

Y1 circuit is powered from the main circuit board on pin 6 (*). Pin 6 completes the circuit to CR1 relay which opens the (*) CR1 contact to RDV solenoid. This is to make sure discharge bypass circuit is never active during a cooling demand. The circuit continues through the DHRB2 NC contacts and back to pin 5 output Y1 circuit back to main control board.


If system is a 2-stage cooling system, (*) pin 11 sends circuit back to pin 10 and then back to main control board.

COMPRESSOR "Y1" CONTACTOR CIRCUIT






COMPRESSOR "Y2" CONTACTOR CIRCUIT





REHEAT CONTROL BOARD - HOT GAS REHEAT MODE



Tran 2 transformer powers the control circuit to Reheat contacts and solenoids.

We must also consider the 24vac circuit powering pin 9 (*) on the reheat board because it is now responsible for completing blower circuit and Y1 circuit since there is no call for cool or "G" circuit.


When demand for dehumidification occurs without a call for cooling,(*) reheat solenoids are energized.

N/O contacts for DHRA close (*) and complete 24 vac to pin 8 blower circuit. (*) N/O DHRA2 contacts (*) close energizing the cooling liquid valve.

Remember, if there is no call for cooling, no 24v
 on Y1 the gray wire pin 6 does not energize (*)
 CR1 relay. (*) CR1 N/C contacts are closed allowing circuit to energize discharge solenoid valve. (*) N/O DHRB2 points are closed and send 24v from J1-9 pin to J1-5 making the compressor contactor circuit.




"W" HEAT MODE



ĈE

Any call for heating cycle will disable HG Reheat mode by opening HR1 N/C points. After heat demand is satisfied, system returns back to reheat mode if demanded as long as ODT is above the 40 degree.

MOTORMASTER SENSORS






CHARGING A HUMIDIMIZER

The subcooling/reheat dehumidification coil liquid line solenoid valve MUST be energized to use the charging chart

Sub-cooling mode = circuit must have call for H, and Y1/Y2


- On TB-1, jumper "R" to Y1 and Y2
- In unit control box, jumper the two pink "DEHUM" wires





CHARGING A HUMIDIMIZER

Bypass the low ambient controller to allow the condenser fans to run at full speed.





TROUBLESHOOTING

PROBLEM	CAUSE	REMEDY
Subcooling Mode Will Not	No power to control transformer from	Check power source and evaporator-fan relay.
Energize	evaporator-fan motor.	Ensure all wire connections are tight.
	No power from control transformer to	1. Fuse open; check fuse. Ensure continuity of
	liquid line solenoid valve.	wiring.
		2. Low-pressure switch open. Cycle unit off and
		allow low-pressure switch to reset. Replace
		switch if it will not close.
		3. Transformer bad; check transformer.
	Liquid line solenoid valve will not operate.	1. Solenoid coil defective; replace.
		2. Solenoid valve stuck open; replace.
	Liquid line solenoid valve will not open.	Valve is stuck closed; replace valve.
Low System Conseity	Low refrigerant charge or frosted	1. Check charge amount. Charge per
Low System Capacity	evaporator coil.	HumidiMiZer charging chart.
		2. Evaporator coil frosted; check and replace
		low-pressure switch if necessary.
Loss of Compressor		1. Check TXV bulb mounting, and secure
Superheat Conditions with	Thermostatic expansion valve (TXV)	tightly to suction line.
Subcooling/Reheat		
Dehumidification Coil		2. Replace TXV if stuck open or closed.
Energized		



TROUBLESHOOTING - CONT'D

PROBLEM	CAUSE	REMEDY
Reheat Mode Will Not	No power to control transformer from	Check power source and evaporator-fan relay.
Energize	evaporator-fan motor.	Ensure all wire connections are tight.
	No power from control transformer to hot	1. Fuse open; check fuse. Ensure continuity of
	gas line solenoid valve.	wiring.
		2. Low-pressure switch open. Cycle unit off and
		allow low-pressure switch to reset. Replace
		switch if it will not close.
		3. Transformer bad; check transformer.
	Hot gas line solenoid valve will not operate.	1. Solenoid coil defective; replace.
		2. Solenoid valve stuck closed; replace.
	Low refrigerant charge or frosted	1. Check charge amount. Charge per
	evaporator coil.	HumidiMiZer charging chart.
		2. Evaporator coil frosted; check and replace
		low-pressure switch if necessary.
Excessive Superheat	Liquid line solenoid valve will not operate.	Valve is stuck; replace valve.
	Hot gas line solenoid valve will not close.	Valve is stuck; replace valve.



End of Deck LCU Pt 1 Please transition to Deck LCU Pt 2

